



all types of vinyl and leather.

Compound is fully cured when h

Keep compound in a cool dry p  
avoid semi curing in container.

12.

**Apply compound onto spat**



Scoop out a small amount of co  
spatula. Be careful not to apply  
placed on the repair. You only n  
the repair area without protrusio

Compound will be stringy so us

13.

**Apply compound to repair**



Apply (place) compound onto th  
Lift spatula then wipe clean usir



Screen compound across the re  
sweeping motion (do not dab).  
out too far leaving a mess. Con  
area. This will help you to achiev