



If you are doing a repair where the top coat requires blending into the original paintwork, you must scuff the surrounding surface for this process.

Scuff the surrounds using scotch-brite to blend the original paintwork assisting adhesion of the new paint and fade out when applied.

12.

Wipe area



After scuffing, wipe area down again with a clean cloth to remove any residue.

13.

Mask out area (if part not removed)



Mask out undamaged area that does not require repair.

When spraying paint be very careful not to spray paint onto undamaged surfaces.

14.

Colour match paint